
DMX-INTERFACE

DSWG512







FEATURES


- Auto address allocation
- Internal resolution: 16 Bit (65.536 steps)
- Emergency light function (in case of missing DMX signal)
- Support for instant ON/OFF (flash/blackout)
- Upscaling enables to use low-cost Light-Mixing Tools for professional applications
- Customer specific upgrade options due to firmware update capabilities on request


Protocol: DMX-512-A Supply-Voltage: 12V Max. Current: 25mA

Insulation strength DMX Input: 500V










CE-label according to:2006/95/EC: EN 50178
2004/108/EC: EN 61000-6-1
EN 61000-6-3



DMX-INTERFACE







OPERATING INSTRUCTIONS

- Connect the interface to the 15-pin SUB-D Connector of the soft-LED Dimming-Driver
- The green colour of the LED indicates the interface is ready for use
- To start the Auto-Address-Algorythm, press the switch-key (located on the upper side) for 5 seconds till the LED switches to red colour. Now the interface is in the programming-mode
- To allocate a specific address just fade the DMX-Channel you want to programm from MIN to MAX position 2 times
- By jumping back to green colour the LED indicates the DMX address was programmed to the interface successfully
- If you want to programm another address you can repeat these steps as often as you want





